



Salvo Spinning Guide Kit Spacing

Spacing measured in inches from tip top ring to guide ring, starting from the tip. Spacing is based on uplocking reel seats.

Rod Length	Rear Grip Length*	1	2	3	4	5	6	7	8	9	10	11	12
5'0"	4"	3"	6 1/2"	10 3/4"	15 3/4"	22 1/4"	29 3/4"						
5'6"	5"	3"	6 1/2"	10 3/4"	15 1/2"	20 7/8"	27 5/8"	35 1/2"					
6'0"	6"	3"	6 1/2"	10 3/4"	14 7/8"	19 3/4"	25 1/2"	32 1/4"	40 1/4"				
6'3"	6"	3 1/4"	6 3/4"	11"	15 1/2"	20 3/4"	26 1/2"	33 3/4"	42 1/4"				
6'6"	7"	3 3/8"	7"	11 3/8"	16 1/4"	21 3/4"	28 1/4"	35 5/8"	44 3/8"				
6'9"	8"	3 3/8"	7"	11 3/8"	16 1/2"	22 1/2"	29 1/4"	37"	47"				
6'10"	8"	3 3/8"	7"	11 1/2"	16 1/2"	22 1/2"	29 5/8"	37 5/8"	47"				
7'0"	9"	3 3/8"	7"	11 1/2"	17 1/8"	23 3/8"	30 3/8"	38 1/4"	47 1/4"				
7'2"	9"	3 1/4"	6 3/4"	10 3/8"	14 1/2"	19 3/4"	25 3/4"	32 7/8"	40 3/4"	50"			
7'3"	9"	3 1/4"	6 3/4"	10 3/8"	14 1/2"	19 3/8"	26 1/4"	33 5/8"	41 5/8"	50 7/8"			
7'4"	10"	3 1/4"	6 3/4"	10 3/8"	14 5/8"	20"	26 3/8"	33 3/4"	41 3/4"	51"			
7'6"	10"	3 5/16"	6 7/8"	10 7/16"	14 3/4"	19"	24"	29 1/2"	36 1/4"	44"	53"		
7'9"	10"	3 3/8"	7"	10 7/8"	15"	19 3/8"	24 3/8"	30 1/4"	37 1/4"	45 1/8"	54 1/2"		
7'11"	10"	3 3/8"	7"	10 7/8"	15 1/8"	19 3/4"	25 3/8"	31 5/8"	38 5/8"	46 7/8"	56 3/8"		
8'0"	11"	3 1/4"	7 1/8"	10 3/4"	14 3/4"	19 1/2"	25 3/8"	31 1/2"	38 1/2"	46 3/4"	56 1/4"		
8'6"	12"	3 1/2"	7 1/4"	10 7/8"	15"	20"	25 1/8"	30 5/8"	36 3/4"	43 3/4"	52"	61 1/2"	
9'0"	14"	3 1/2"	7 1/4"	11 1/8"	15 1/8"	19 5/8"	24 5/8"	30"	35 5/8"	41 1/4"	48"	55 7/8"	65 1/2"

*Rear Grip Length is measured from the butt to the rear edge of the reel seat.

The guide spacing shown in this chart is a general recommendation suitable for many applications. However, you may need to adjust it slightly to better fit your specific rod blank and application needs.